

RainFlo Water Treatment Panel

IMPORTANT

Please read before start up.

- Begin the installation by locating a suitable area for the filtration panel. Typically a mechanical room or some area where easy access to the panel is available. It is imperative that there be enough room above the UV to lift the bulb out for replacement. Secure panel to wall with suitable fasteners that will support the weight of the panel plus several gallons of water.
- Important: The UV does not have the sleeve and bulb installed. The sleeve and bulb will need to be installed after the panel is securely in place. Refer to the Viqua instructions, included in the Viqua UV disinfection unit box (along with the bulb and sleeve), for proper installation and startup of the UV disinfection unit.
- Cutoff or isolation valves should be installed on the inlet and outlet connections of the panel.
- Make the inlet connection to the filters housings on the inlet side of the panel.
- Make the outlet connection on the flow restrictor or outlet of the UV.
- Using the filter wrench, remove the filters from the housings and remove the cellophane wrapping from the filters. Reinstall the filters and make sure the housings are snug but do not overtighten.
- Before turning water on, make sure all connections are tight.
- If any of the connections have a small leaks it may be necessary to use thread sealant and retighten.